

Contents

Preface	xiii
Acknowledgments	xvii
About the Authors	xix
1 UMTS Basics	1
1.1 Standards	2
1.2 Network Architecture	4
1.2.1 GSM	4
1.2.2 UMTS Release 99	5
1.2.3 UMTS Release 4	7
1.2.4 UMTS Release 5	8
1.2.5 HSPA	12
1.2.6 UMTS Release 6	21
1.2.7 UMTS Release 7 and Beyond	24
1.2.8 TD-SCDMA	26
1.3 UMTS Interfaces	28
1.3.1 Iu Interface	28
1.3.2 Iub Interface	29
1.3.3 Iur Interface	29
1.4 UMTS Domain Architecture	31
1.5 UTRAN	31
1.5.1 RNC	33
1.5.2 Node B	35
1.5.3 Area Concept	35
1.5.4 UMTS User Equipment and USIM	36
1.5.5 Mobiles	38
1.5.6 QoS Architecture	39
1.6 UMTS Security	41
1.6.1 Historic Development	41
1.6.2 UMTS Security Architecture	46
1.6.3 Authentication and Key Agreement (AKA)	48
1.6.4 Kasumi/Misty	53
1.6.5 Integrity – Air Interface Integrity Mechanism	55

1.6.6	<i>Confidentiality – Encryption (Cipherng) on Uu and Iub</i>	58
1.6.7	<i>UMTS Network Transactions</i>	63
1.7	Radio Interface Basics	63
1.7.1	<i>Duplex Methods</i>	64
1.7.2	<i>Multiple Access Methods</i>	64
1.7.3	<i>UMTS CDMA</i>	65
1.7.4	<i>CDMA Spreading/Channelization</i>	66
1.7.5	<i>Microdiversity – Multipath (FDD and TDD)</i>	67
1.7.6	<i>Microdiversity – Softer Handover (FDD)</i>	67
1.7.7	<i>Macrodiversity – Soft Handover (FDD)</i>	68
1.7.8	<i>UMTS Spreading (FDD and TDD)</i>	68
1.7.9	<i>Scrambling</i>	69
1.7.10	<i>Coding Summary (FDD)</i>	69
1.7.11	<i>Signal to Interference (FDD)</i>	69
1.7.12	<i>Cell Breathing (FDD)</i>	70
1.7.13	<i>UMTS Channels (FDD and TDD)</i>	72
1.7.14	<i>Transport Channels (FDD and TDD)</i>	74
1.7.15	<i>Common Transport Channels (FDD and TDD)</i>	74
1.7.16	<i>Dedicated Transport Channels (FDD and TDD)</i>	75
1.7.17	<i>Initial UE Radio Access (FDD)</i>	76
1.7.18	<i>Power Control (FDD and TDD)</i>	77
1.7.19	<i>UE Random Access (FDD)</i>	79
1.7.20	<i>Power Control in Soft Handover (FDD)</i>	80
1.8	UMTS Network Protocol Architecture	81
1.8.1	<i>Iub – Control Plane</i>	82
1.8.2	<i>Iub – User Plane</i>	83
1.8.3	<i>Iur – User/Control Plane</i>	84
1.8.4	<i>IuCS – User/Control Plane</i>	85
1.8.5	<i>IuPS – User/Control Plane</i>	86
1.8.6	<i>E – User/Control Plane</i>	86
1.8.7	<i>Gn – User/Control Plane</i>	87
1.9	SIGTRAN	87
1.10	ATM	89
1.10.1	<i>ATM Cell</i>	90
1.10.2	<i>ATM Layer Architecture</i>	91
1.10.3	<i>ATM Adaption Layer (AAL)</i>	91
1.10.4	<i>AAL2</i>	92
1.10.5	<i>AAL5</i>	92
1.11	User Plane Framing Protocol	93
1.11.1	<i>Frame Architecture</i>	93
1.11.2	<i>FP Control Frame Architecture</i>	94
1.12	Medium Access Protocol (MAC)	95
1.12.1	<i>MAC Architecture</i>	95
1.12.2	<i>MAC Data PDU</i>	96
1.12.3	<i>MAC Header Alternatives</i>	98

1.13	Radio Link Control (RLC)	98
1.13.1	<i>RLC Services</i>	99
1.13.2	<i>RLC Functions</i>	100
1.13.3	<i>RLC Architecture</i>	102
1.13.4	<i>RLC Data PDUs</i>	103
1.13.5	<i>Other RLC PDUs</i>	104
1.14	Service Specific Connection Oriented Protocol (SSCOP)	104
1.14.1	<i>Example SSCOP</i>	105
1.15	Service Specific Coordination Function (SSCF)	106
1.16	Message Transfer Part Level 3 – Broadband (MTP3-B)	106
1.17	Internet Protocol (IP)	107
1.17.1	<i>IPv4 Frame Architecture</i>	108
1.18	Signaling Transport Converter (STC)	108
1.19	Signaling Connection Control Part (SCCP)	109
1.19.1	<i>Example SCCP</i>	110
1.20	Abstract Syntax Notation One (ASN.1) in UMTS	111
1.20.1	<i>ASN.1 BER</i>	111
1.20.2	<i>ASN.1 PER</i>	112
1.21	Radio Resource Control (RRC)	112
1.21.1	<i>RRC States (3GPP 25.331)</i>	113
1.21.2	<i>System Information Blocks (SIBs)</i>	118
1.22	Node B Application Part (NBAP)	124
1.22.1	<i>NBAP Functions</i>	124
1.22.2	<i>NBAP Elementary Procedures (EPs)</i>	125
1.22.3	<i>Example – NBAP</i>	126
1.23	Radio Network Subsystem Application Part (RNSAP)	126
1.23.1	<i>RNSAP Functions</i>	126
1.23.2	<i>Example – RNSAP Procedures</i>	127
1.24	Radio Access Network Application Part (RANAP)	128
1.24.1	<i>RANAP Elementary Procedures (EPs)</i>	129
1.24.2	<i>Example – RANAP Procedure</i>	131
1.25	ATM Adaptation Layer Type 2 – Layer 3 (AAL2L3/ALCAP)	131
1.25.1	<i>AAL2L3 Message Format</i>	131
1.25.2	<i>Example – AAL2L3 Procedure</i>	132
1.26	IU User Plane Protocol	134
1.26.1	<i>Iu UP Transparent Mode</i>	134
1.26.2	<i>Iu UP Support Mode Data Frames</i>	134
1.26.3	<i>Iu UP Support Mode Control Frames</i>	136
1.26.4	<i>Example – Iu UP Support Mode Message Flow</i>	136
1.27	Adaptive Multirate (AMR) Codec	136
1.27.1	<i>AMR IF1 Frame Architecture</i>	138
1.28	Terminal Adaptation Function (TAF)	138
1.29	Radio Link Protocol (RLP)	139
1.30	Packet Data Convergence Protocol (PDCP)	140
1.30.1	<i>PDCP PDU Format</i>	140

1.31	Broadcast/Multicast Control (BMC)	141
	<i>1.31.1 BMC Architecture</i>	141
1.32	Circuit-Switched Mobility Management (MM)	141
1.33	Circuit-Switched Call Control (CC)	142
1.34	Example – Mobile Originated Call (Circuit Switched)	143
1.35	Packet-Switched Mobility Management (GMM)	144
1.36	Packet-Switched Session Management (SM)	144
1.37	Example – Activate PDP Context (Packet Switched)	145
2	Short Introduction to Network Monitoring, Troubleshooting, and Network Optimization	147
2.1	Iub Monitoring	147
	<i>2.1.1 IMA</i>	147
	<i>2.1.2 Fractional ATM</i>	148
	<i>2.1.3 Load Sharing and Addressing on Iub</i>	149
	<i>2.1.4 Troubleshooting Iub Monitoring Scenarios</i>	150
2.2	Iu Monitoring	151
	<i>2.2.1 Troubleshooting Iu Monitoring</i>	154
2.3	Network Optimization and Network Troubleshooting	155
	<i>2.3.1 Cell-related Performance Relevant Data</i>	159
	<i>2.3.2 Call-related Performance Relevant Data</i>	164
3	UMTS UTRAN Signaling Procedures	171
3.1	Iub – Node B Setup	172
	<i>3.1.1 Overview</i>	172
	<i>3.1.2 Message Flow</i>	173
3.2	Iub – IMSI/GPRS Attach Procedure	191
	<i>3.2.1 Overview</i>	191
	<i>3.2.2 Message Flow</i>	192
3.3	Iub CS – Mobile Originated Call	205
	<i>3.3.1 Overview</i>	206
	<i>3.3.2 Message Flow</i>	207
3.4	Iub CS – Mobile Terminated Call	217
	<i>3.4.1 Overview</i>	217
	<i>3.4.2 Message Flow</i>	219
3.5	Iub PS – PDP Context Activation/Deactivation	223
	<i>3.5.1 Overview</i>	225
	<i>3.5.2 Message Flow</i>	226
3.6	Iub – IMSI/GPRS Detach Procedure	235
	<i>3.6.1 Overview</i>	235
	<i>3.6.2 Message Flow</i>	236
3.7	RRC Measurement Procedures	239
	<i>3.7.1 RRC Measurement Types</i>	239
	<i>3.7.2 Cell Categories</i>	239

3.7.3	<i>Measurement Initiation for Intrafrequency Measurement</i>	240
3.7.4	<i>Intrafrequency Measurement Events</i>	241
3.7.5	<i>Intrafrequency Measurement Report</i>	244
3.7.6	<i>Intrafrequency Measurement Modification</i>	245
3.7.7	<i>Measurement Initiation for Interfrequency Measurement</i>	247
3.7.8	<i>Further RRC Measurement Groups</i>	248
3.7.9	<i>Changing Reporting Conditions After Transition to CELL_FACH</i>	249
3.8	Iub – Physical Channel Reconfiguration (PDPC)	250
3.8.1	<i>Message Flow</i>	251
3.9	Channel Type Switching	259
3.9.1	<i>Overview</i>	259
3.9.2	<i>Message Flow</i>	261
3.10	Iub – Mobile-Originated Call with Soft Handover (Inter-Node B, Intra-RNC)	272
3.10.1	<i>Overview</i>	272
3.10.2	<i>Message Flow (Figure 3.70)</i>	273
3.11	Iub – Softer Handover	286
3.11.1	<i>Overview</i>	286
3.11.2	<i>Message Flow</i>	287
3.12	Iub Interfrequency Hard Handover FDD	290
3.12.1	<i>Interfrequency Hard Handover Overview</i>	291
3.12.2	<i>FDD Interfrequency Inter-Node B Hard Handover Call Flow</i>	292
3.13	RRC Measurements in Compressed Mode and Typical Call Drop	296
3.13.1	<i>Message Flow</i>	296
3.14	High Speed Downlink Packet Access (HSDPA)	301
3.14.1	<i>HSDPA Cell Setup</i>	302
3.14.2	<i>HSDPA Basic Call</i>	304
3.14.3	<i>Mobility Management and Handover Procedures in HSDPA</i>	310
3.14.4	<i>Troubleshooting HSDPA Calls</i>	318
3.14.5	<i>Proprietary Descriptions of HSDPA Call/Mobility Scenarios</i>	320
3.15	High Speed Uplink Packet Access (HSUPA)	323
3.15.1	<i>HSUPA Cell Setup</i>	324
3.15.2	<i>HSUPA Call Scenarios</i>	325
3.15.3	<i>HSUPA Basic Call</i>	328
3.16	NBAP Measurements	330
3.16.1	<i>NBAP Common Measurements</i>	331
3.16.2	<i>NBAP Dedicated Measurements</i>	334
4	TDD (TD-SCDMA) Iub Signaling Procedures	339
4.1	TD-SCDMA Radio Interface Structure and Radio Resource Allocation	340
4.1.1	<i>TD-SCDMA Mobile Originated Speech Call Setup</i>	343
4.1.2	<i>RRC Measurements in TD-SCDMA Radio Mode</i>	349
4.1.3	<i>Intra-Cell Interfrequency Handover in TD-SCDMA</i>	352
4.1.4	<i>Inter-Cell Interfrequency Handover</i>	353
4.1.5	<i>Multi-Service Call CS/PS with Inter-Node B Handover</i>	356

5	Iu and Iur Signaling Procedures	363
5.1	Iub-Iu – Location Update	363
	5.1.1 <i>Message Flow</i>	364
5.2	Iub-Iu – Mobile-Originated Call	370
	5.2.1 <i>Overview</i>	370
	5.2.2 <i>Message Flow</i>	372
5.3	Iub-Iu – Mobile-Terminated Call	378
	5.3.1 <i>Overview</i>	378
	5.3.2 <i>Message Flow</i>	379
5.4	Iub-Iu – Attach	384
	5.4.1 <i>Overview</i>	384
	5.4.2 <i>Message Flow</i>	385
5.5	Iub-Iu – PDPC Activation/Deactivation	387
	5.5.1 <i>Overview</i>	387
	5.5.2 <i>Message Flow</i>	388
5.6	Streaming PS Service and Secondary PDP Context	394
	5.6.1 <i>Message Flow</i>	395
5.7	Iub-Iu – Detach	398
	5.7.1 <i>Overview</i>	398
	5.7.2 <i>Message Flow</i>	399
5.8	Iub-Iur – Soft Handover (Inter-Node B, Inter-RNC)	401
	5.8.1 <i>Overview</i>	401
	5.8.2 <i>Message Flow</i>	402
5.9	Iub-Iu – RRC Re-Establishment (Inter-Node B, Inter-RNC)	412
	5.9.1 <i>Overview</i>	412
	5.9.2 <i>Message Flow</i>	414
5.10	SRNS Relocation (UE not Involved)	419
	5.10.1 <i>Overview</i>	420
	5.10.2 <i>Message Flow</i>	421
5.11	SRNS Relocation (UE Involved)	426
	5.11.1 <i>Overview</i>	427
	5.11.2 <i>Message Flow</i>	429
5.12	Short Message Service (SMS) in UMTS Networks	437
	5.12.1 <i>SMS Network Architecture Overview</i>	437
	5.12.2 <i>SMS Protocol Architecture</i>	438
	5.12.3 <i>Mobile-Originated Short Message</i>	439
	5.12.4 <i>Mobile-Terminated Short Message</i>	446
6	Signaling Procedures in the 3G Core Network	453
6.1	ISUP/BICC Call Setup	453
	6.1.1 <i>Address Parameters for ISUP/BICC Messages</i>	454
	6.1.2 <i>ISUP Call (Successful)</i>	454
	6.1.3 <i>ISUP Call (Unsuccessful)</i>	455
	6.1.4 <i>BICC Call Setup on E Interface Including IuCS Signaling</i>	458
6.2	Gn Interface Signaling	462
	6.2.1 <i>PDF Context Creation on Gn (GTP-C and GTP-U)</i>	464

6.2.2	<i>GTP-C Location Management</i>	465
6.2.3	<i>GTP-C Mobility Management</i>	465
6.2.4	<i>SGSN Relocation</i>	467
6.2.5	<i>Example GTP</i>	467
6.3	Procedures on the Gs Interface	469
6.3.1	<i>Location Update via Gs</i>	469
6.3.2	<i>Detach Indication via Gs</i>	470
6.3.3	<i>Paging via Gs</i>	470
6.4	Signaling on Interfaces Toward HLR	470
6.4.1	<i>Addressing on MAP Interfaces</i>	472
6.4.2	<i>MAP Architecture</i>	473
6.4.3	<i>MAP Signaling Example</i>	475
6.5	Inter-3G_MSC Handover Procedure	477
6.5.1	<i>Inter-3G_MSC Handover Overview</i>	480
6.5.2	<i>Inter-3G_MSC Handover Call Flow</i>	482
6.6	Inter-3G-2G-3G_MSC Handover Procedure	486
6.6.1	<i>Inter-3G-2G_MSC Handover/Relocation Overview (Figure 6.42)</i>	489
6.6.2	<i>Inter-3G-2G_MSC Handover Call Flow</i>	490
6.6.3	<i>Inter-3G-2G_MSC Handover Messages on E Interface</i>	494
6.6.4	<i>Inter-2G-3G_MSC Handover/Relocation Overview</i>	495
6.6.5	<i>Inter-2G-3G_MSC Subsequent Handover Messages on the E Interface</i>	500
6.6.6	<i>2G-3G CS Inter-RAT Handover on IuCS and Iub Interface</i>	501
6.6.7	<i>PS Inter-RAT Mobility</i>	506
6.7	Customized Application for Mobile Network Enhanced Logic (CAMEL)	509
6.7.1	<i>IN/CAMEL Network Architecture</i>	510
6.7.2	<i>CAMEL Basic Call State Model</i>	511
6.7.3	<i>Charging Operation Using CAMEL</i>	512
6.7.4	<i>CAMEL Signaling Example for GPRS Charging</i>	513
6.8	IP Multimedia Subsystem (IMS)	517
6.8.1	<i>IMS PDP Context Activation Basics</i>	517
6.8.2	<i>IMS UE-UE Call Basics</i>	518

Glossary	521
-----------------	------------

Bibliography	537
---------------------	------------

Index	541
--------------	------------